

Drawer Adjustment

This Westwood chest has state of the art center mounted ball bearing tracks. **These tracks have a memory.** If your drawers do not pull out at least 2/3 of the length of the drawer, give them a bit of a tug until they do. This will reset the memory of the track system. This is best accomplished by taking everything off the top of the chest (and out of the drawer), opening the drawer and grasping it in the middle, and then giving it a strong tug or series of tugs until the drawer reaches the 2/3 extension.

The drawer tracks also have a stop to keep the drawers from falling out. To remove a drawer, follow the procedure above, but keep tugging until the drawer comes out. This can feel like it requires a lot of force- this is normal.

To replace the drawer, simply line up the tracks and push the drawer in. The stop will reset itself.



635 N. Billy Mitchell Rd., Ste. B
Salt Lake City, UT 84116
Phone: 1-908-719-4707
support@westwoodbaby.com

October 18, 2007